


**MODEL NO. 8016 ALM**



**US 8016ALM**

NOTE:When ordering spare parts.Please state the part name and part number

No.	Part NO.	Name	PCS	No.	Part NO.	Name	PCS
1	52010	Hammer Cap Hammer	1	26	91001	Hex.HD Soc Screw	2
2	90087	O-Ring	1	27	18140	Nose	1
3	90000	O-Ring	1	28	18150	Nose Plate	1
4	90001	O-Ring	1	29	18161	Magazine	1
5	18020	Piston Ram Assembly	1	30	93001	Hex. Soc. FT HD Screw	3
6	90000	O-Ring	1	31	98006	Hex. Soc. FT HD Screw	2
7	90015	O-Ring	1	32	18212	Magazine Retainer	1
8	18040	Cylinder	1	33	51213	Air Silencer	1
9	18050	Bumper	1	34	18171	Pusher Spring	1
10	18060-1	Trigger Valve Set	1	35	18181	Magazine Cover	1
11	18070	Trigger Valve Spring	1	36	18190	Pusher	1
12	90055	O-Ring	1	37	18200	Rear Magazine Bumper	1
13	18090	Trigger Valve	1	38	18291	Pin	1
14	90006	O-Ring	1	39	18340	Latch Bracket	1
15	90008	O-Ring	1	40	95001	E-Ring	1
16	18310	Trigger Valve plate	1	41	18322-1	Automatic adjust switch kit	1
17	90005	O-Ring	1	42	18220	Pin	1
18	90033	O-Ring	1	43	18240	Seal	1
19	90009	O-Ring	1	44	52040	Trigger	1
20	18110	Trigger Valve Stem	1	47	94001-1	Air Plug	1
21	90033	O-Ring	1	48	18281	Magazine Latch	1
22	18130	Trigger Valve Guide	1	49	18271	Magazine Latch Spring	1
23	90007	O-Ring	1	50	90010	O-Ring	1
24	91000-1	Hex.HD Soc Screw + Spring Wa	2	51	18590	Gun Body	1
25	18332	Seal Retainer	1	52	97003	Nut	1